User’s manual of APTP449

Thanks for purchasing the digital scale from our company. Please read the manual carefully before use it..

Notes

1. Scale is the precise machine, please adjust the scale according to the gradienter till it put on the level place before use it.
2. In order to make sure the precision, You’d better calibrate the scale before the first time use.
3. Please press the tray with the full capacity weight for three minutes when use it for the first time.
4. Don't weigh the goods exceed the maximal weight. If do this, the scale will be destroyed
5. Use the scale under the normal temperature, don’t put it in the too cold or too hot condition.
6. Put the scale in the clear circumstance, dust, dirt, moisture, libration, airflow and the wiring environment will destroy the scale.
7. Avoid swaging, dropping or shaking the scale in order to keep precision.

Operation instruction

1. Press the on/off key, turn on and turn off the scale, when turn off, press this key for three seconds.
2. Begin to use the scale when display 0.00000
3. Units key is used for changing the unit. One press , one unit. There are 13 kinds of unit for choosing.
4. If the scale don’t show 0.00000 when turn on, please press the key “tare”
5. “Mode” is used for function changing. It can be changed among “％”、”G”、”PCS”.

Calibration

1. It will display 0.00000 when turn on
2. Press the “TARE” for two seconds until display “CALL”, then show “1”, the first calibration value, the second calibration value, then the inner code number. When the number is stable (appear a small circle below the number), press “ON/OFF” key, it will show “CAL-1”, then “0” （if can’t become zero, press tare）, then put the first calibration weight on plate, it will show “PASS-1”, then “CAL-2” and “0”, at this time, please take off the first calibration weights immediately, and put on the second calibration weights. It will show “PASS-2”, the calibration is finished. (n
3. If any fault, pls repeat the process the above.